

CAVI DI SEGNALE		
Codice originale	Codice equivalente Agencavi Systems	Applicazione
R7A-CPBXXX-S	ACOML5CPBS	POSA FISSA
R88A-CFKAxxxCR-E	ACOMH-CFKACRE	POSA MOBILE
R88A-CFKBxxxCR-E	ACOMH-CFKBCRE	POSA MOBILE
R88A-CFKCxxxCR-E	ACOMH-CFKCCRE	POSA MOBILE
R88A-CFKDxxxCR-E	ACOMH-CFKDCRE	POSA MOBILE
R88A-CR1AxxxCF-E	ACOMH-CR1ACFE/1	POSA MOBILE
R88A-CR1AxxxCF-E	ACOMH-CR1ACFE/2	POSA MOBILE
R88A-CR1AxxxNF-E	ACOMH-CR1BNFE/1	POSA MOBILE
R88A-CR1AxxxNF-E	ACOMH-CR1BNFE/2	POSA MOBILE
R88A-CRGAxxxCR-E	ACOMH-CRGACRE	POSA MOBILE
R88A-CRGBxxxCR-E	ACOMD-CRGCRCRE	POSA INTERMEDIA
R88A-CRGC0xxNR-E	ACOMH-CRGCNRE	POSA MOBILE
R88A-CRKA0xxCR-E	ACOMH-CRKACRE	POSA MOBILE
R88A-CRKC0xxNR-E	ACOMH-CRKCNCRE	POSA MOBILE
R88A-CRKNxxxCR-E	ACOML-CRKNCRE	POSA FISSA
R88A-CRWAxxC	ACOMH-CRWAC	POSA MOBILE
R88A-CRWAxxxC-DE	ACOMD-CRWACDE	POSA INTERMEDIA